



Rigging & Assembly Instructions

PHC-E SERIES

PARALLEL HYBRID
EVAPORATIVE
CONDENSERS



Mr. GoodTower



PHCE26RIG






Table of Contents


Method of Shipment	1
Storage	1
General	1
International Building Code Provisions	1
Structural Steel Support	1
Rigging the Basin Section	2
Extended Lifts	3
Applying Sealer Tape	4
Rigging Coil / Fan Section	4
Assembly of the Coil / Fan Section to the Basin Section	5
Mounting Fan Screens	6
Final Assembly & Startup Details	7
Appendix A	9
Notes	10

The PHC-E SERIES FORCED DRAFT EVAPORATIVE CONDENSERS should be rigged and assembled using the instructions and recommendations outlined in this bulletin.

All personnel should review these procedures, as well as the latest industry-approved installation practices, prior to rigging and assembly. The information in this bulletin is for informational purposes only. These instructions do not purport to cover all variations and possible contingencies in connection with installation. Additionally, the procedures described herein are subject to change without prior notice, due to EVAPCO, Inc.'s ongoing research and development.

EVAPCO, Inc. makes no representations or warranties with respect to these instructions or the products described herein. Nor shall EVAPCO, Inc. be responsible for any loss or damage (direct, indirect, consequential, or other) during installation or handling of equipment after shipment.

For a full description of EVAPCO's liability policy, please visit www.evapco.com to access our Terms and Conditions.



**FOR EVAPCO AUTHORIZED
PARTS AND SERVICE,
CONTACT YOUR
LOCAL EVAPCO
REPRESENTATIVE
OR THE LOCAL
SERVICE CENTER**



Mr. GoodTower®



EVAPCO, Inc. — World Headquarters & Research/Development Center

P.O. Box 1300 • Westminster, MD 21158 USA
410.756.2600 • marketing@evapco.com • evapco.com

North America

EVAPCO, Inc.
World Headquarters
Westminster, MD USA
410.756.2600
marketing@evapco.com

EVAPCO East
Taneytown, MD USA

EVAPCO East
Key Building
Taneytown, MD USA

EVAPCO Midwest
Greenup, IL USA
217.923.3431
evapcomw@evapcomw.com

Evapcold Manufacturing
Greenup, IL USA

EVAPCO Newton
Newton, IL USA
618.783.3433
evapcomw@evapcomw.com

EVAPCO West
Madera, CA USA
559.673.2207
contact@evapcowest.com

EVAPCO Alcoil, Inc.
York, PA USA
717.347.7500
info@evapco-alcoil.com

EVAPCO Iowa
Lake View, IA USA

EVAPCO Iowa
Sales & Engineering
Medford, MN USA
507.446.8005
evapcomn@evapcomn.com

EVAPCO LMP ULC
Laval, Quebec, Canada
450.629.9864
info@evapcolmp.ca

EVAPCO Select Technologies, Inc.
Belmont, MI USA
844.785.9506
emarketing@evapcoselect.com

**Refrigeration Vessels &
Systems Corporation**
Bryan, TX USA
979.778.0095
rvs@rvscorp.com

Tower Components, Inc.
Ramseur, NC USA
336.824.2102
mail@towercomponentsinc.com

EvapTech, Inc.
Edwardsville, KS USA
913.322.5165
marketing@evaptech.com

EvapTech Gulf Services
Houston, TX USA
281.529.6526
angie.montes@evaptech.com

EVAPCO Dry Cooling, Inc.
Bridgewater, NJ USA
908.379.2665
info@evapcodc.com

EVAPCO Dry Cooling, Inc.
Littleton, CO USA
908.895.3236
info@evapcodc.com

Asia Pacific

**EVAPCO Asia Pacific
Headquarters**
Baoshan Industrial Zone Shanghai, P.R. China
(86) 21.6687.7786
marketing@evapcochina.com

**EVAPCO (Shanghai)
Refrigeration Equipment Co., Ltd.**
Baoshan Industrial Zone, Shanghai, P.R. China

**EVAPCO (Beijing)
Refrigeration Equipment Co., Ltd.**
Huairou District, Beijing, P.R. China
(86) 10.6166.7238
marketing@evapcochina.com

**EVAPCO Air Cooling Systems
(Jiaxing) Company, Ltd.**
Jiaxing, Zhejiang, P.R. China
(86) 573.8311.9379
info@evapcochina.com

EVAPCO Australia (Pty.) Ltd.
Riverstone, NSW, Australia
(61) 02.9627.3322
sales@evapco.com.au

**EvapTech (Shanghai)
Cooling Tower Co., Ltd**
Baoshan District, Shanghai, P.R. China.
Tel: (86) 21.6478.0265

EvapTech Asia Pacific Sdn. Bhd.
Puchong, Selangor, Malaysia
(60) 3.8070.7255
marketing-ap@evaptech.com

Europe | Middle East | Africa

**EVAPCO Europe
EMENA Headquarters**
Tongeren-Borgloon, Belgium
(32) 12.39.50.29
evapco.europe@evapco.be

EVAPCO Europe BV
Tongeren-Borgloon, Belgium

EVAPCO Europe, S.r.l.
Milan, Italy
(39) 02.939.9041
evapcoeuropa@evapco.it

EVAPCO Europe, S.r.l.
Sondrio, Italy

EVAPCO Europe A/S
Aabybro, Denmark
(45) 9824.4999
info@evapco.dk

EVAPCO Europe GmbH
Meerbusch, Germany
(49) 2159.69560
info@evapco.de

EVAPCO Middle East DMCC
Dubai, United Arab Emirates
(971) 56.991.6584
info@evapco.ae

Evap Egypt Engineering Industries Co.
A licensed manufacturer of EVAPCO, Inc.
Nasr City, Cairo, Egypt
(20) 10.054.32198
evapco@tiba-group.com

EVAPCO S.A. (Pty.) Ltd.
A licensed manufacturer of EVAPCO, Inc.
Isando, South Africa
(27) 11.392.6630
evapco@evapco.co.za

South America

EVAPCO Brasil
Equipamentos Industriais Ltda.
Sorocaba, São Paulo, Brazil
(55) 11.5681.2000
vendas@evapco.com.br

FanTR Technology Resources
Sorocaba, São Paulo, Brazil
(55) 11.4025.1670
fantr@fantr.com

TECHNOLOGY FOR THE FUTURE, AVAILABLE TODAY

Visit EVAPCO's website: evapco.com



Method of Shipment

PHC-E condensers are shipped with the top section(s) separate from the bottom section(s). These sections have mating flanges and will join together in a waterproof joint when sealed and bolted together as described in the following instructions. Miscellaneous items, such as sealer, fasteners and any other required materials, are packaged and placed inside the pan for shipment.

Storage

Do not place tarps or other coverings over the top of the units if the units are to be stored before installation. Excessive heat can build up if the units are covered causing possible damage to the PVC crossflow fill and eliminators. For extended storage, rotate the fan and fan motor shaft(s) monthly. Beyond six months, the fan shaft bearings should be purged and regreased prior to startup.

General

For extended lifts, or where hazards may exist, it is recommended that safety slings and spreaders be employed for safety. Refer to the "Extended Lifts" section in this bulletin.

NOTE: *All casing sections are factory inspected prior to shipment to verify proper fit for rigging. Please take extra care to handle and rig unit sections per the instructions of this manual to avoid possible distortion and cause poor casing alignment. It is advisable to check each section upon receipt and during each lift to ensure that the factory alignment has not been altered. Should the field inspection indicate the section alignment ("square") has been altered, please contact the factory or your local EVAPCO sales representative for additional instructions to obtain proper section fit.*

Structural Steel Support

PHC-S-E

Two structural I-beams running the length of the unit are required for supporting the unit. These beams should be located underneath the outer flanges of the unit. (See **Figure 1**)

PHC-D-E Models

Three structural I-beams running the width of the unit are required for supporting the unit. Locate two beams underneath the outer flanges of the unit and locate the third beam laterally along the center of the unit. (See **Figure 2**)

All Models

Mounting holes, 3/4" in diameter, are located in the bottom flange for bolting to the structural steel. Refer to the recommended structural steel support drawing and certified print for exact bolt hole location. Bolt the bottom section to the steel support before rigging the top section.

Beams should be sized in accordance with accepted structural practices and the local building code regulations. Maximum deflection of the beam under the unit is recommended to be 1/360 of the unit length, not to exceed 1/2". Deflection may be calculated by using 55% of the operating weight as a uniform load on each beam (see certified print for operating weight).

The supporting I-beams should be level to within 1/8" in 6' before setting the unit. Do not level the unit by shimming between the bottom unit flange and the beams as this will not provide proper longitudinal support.




Figure 1 – Recommended Steel Support for S Models




Figure 2 – Recommended Steel Support for D Models

Tables 1a and 1b – Recommended Steel Support

	PHC-E Pan Footprint Dimensions			
	Box Size	A	B	C
S Models	7x9	86"	-	-
	7x12	86"	-	-
	7x18	86"	-	-
	8.5x6	101"	-	-
	8.5x9	101"	-	-
	8.5x12	101"	-	-
	8.5x18	101"	-	-
	3Mx12	117"	-	-
	3Mx18	117"	-	-
	12x12	142"	-	-
	12x18	142"	--	-
	12x24-2C	142"	-	-
12x36-2C	142"	-	-	

	PHC-E Pan Footprint Dimensions			
	Box Size	A	B	C
D Models	12x24	-	24'	12'
	14x26	-	26'	13'
	24x24-2C	-	24'	12'
	28x26-2C	-	26'	13'

Rigging Basin Section

Lifting devices are located in the lower corners of the basin section for lifting and final positioning purposes as shown in Figures 3 and 4. The bottom of spreader beam must be a minimum dimension of "H" above the lowest lifting ear to prevent undue strain on the lifting devices. See Table 2 for the minimum "H" dimension. These lifting devices should not be used for extended lifts or where any hazard exists unless safety slings are employed under the section. (See "Extended Lifts" section for proper arrangement.) Bolt the basin section to the steel support before rigging the coil / fan section.

Tables 2a and 2b – Dimensions for Basin Sections

Section Size - Unit Type	H	W
7 x 9 - S	8' 10"	7' 4"
7 x 12-S	11' 8"	7' 4"
7 x 18 - S	16' 11"	7' 4"
8.5 x 6 - S	7'	8' 5"
8.5 x 9 - S	8' 10"	8' 5"
8.5 x 12 - S	11' 8"	8' 5"
8.5 x 18 - S	16' 11"	8' 5"
3M x 12 - S	11' 8"	9' 9"

Section Size - Unit Type	H	W
3M x 18 - S	16' 11"	9' 9"
12 x 12 -S	11' 8"	12'
12 x 18 - S	16' 11"	12'
12 x 24-2C - S	11' 8"	12'
12 x 36-2C - S	16' 11"	12'
12 x 24 - D	10' 4"	12'
14 x 26 - D	11' 3"	14'
24 x 24-2C - D	10' 8"	24'
28 x 26-2C - D	11' 7"	26'




Figure 3 — S Model Basin Section – 9’, 12’ and 18’ Long




Figure 4 — D Model Basin Section – 24’ and 26’ Long

Extended Lifts

The recommended method for extended lifts is to use safety slings under the unit (see Figure 5). Spreader bars should always be used between the cables at the top of the section to prevent damage to the upper flanges.

NOTE: The lifting points should be used for final positioning only and for lifting where no danger exists. If they are used for extended lifts, safety slings and spreader bars should be provided under the sections as shown.

Safety slings, spreaders, and skids should be removed before final positioning of the unit.




Figure 5 — Proper Rigging Method for Extended Lifts

Figure 6 — Proper Sealer Tape Application

Applying Sealer Tape

Once the bottom section has been set on the supporting steel and bolted in place, wipe the top flanges to remove any dirt or moisture. Place sealer tape over the mounting holes centerline on the side flanges. Apply two strips of sealer tape, one partially overlapping the other, on the end flanges. The sealer tape should overlap on the corners as shown in **Figure 6**. Do not splice the sealer tape along the end flanges and preferably not on the side flanges if it can be avoided. Always remove the paper backing from the sealer tape.

Rigging Coil / Fan Section

Four lifting ears are provided in the upper corners of the coil / fan sections for lifting. Sections 24' or longer will have two additional lifting ears in the middle of the section. (See **Figures 7-9**)

CAUTION: USE ALL LIFTING EARS PROVIDED ON THE SECTION. A SPREADER BEAM MUST BE USED FOR LIFTING THE TOP SECTION(S) AS SHOWN IN FIGURES 7-9!


 The bottom of the spreader beam must be a minimum dimension "H" above the lowest lifting ear to prevent undue strain on the lifting ears and the section structure. The weight is not evenly distributed across the width of the coil/fan section. Therefore, the top connection of the spreader beam will need to be offset towards the coil side to balance the load. The location of this connection will vary based on the unit configuration. See **Table 3 and Table 4** for the "H" and "W" dimensions. These lifting devices should not be used for extended lifts or where any hazard exists unless safety slings are employed under the section. (See "Extended Lifts" for proper arrangement)

Table 3 – Dimensions for Coil / Fan Sections

Box Size	X Dimension"	Rigging Tolerance ±	Coil Inlet/Outlet Distance Range
7' x 9'	36"	8' 10"	All
7' x 12'	36"	11' 8"	All
7' x 18'	36"	16' 11"	All
8.5x6	42"	7"	All
8.5x9	42"	8' 10"	All
8.5x12	47"	11' 8"	25.75-34.75
8.5x12	41"	11' 8"	43.75-70.75
8.5x18	45"	16' 11"	25.75-34.75
8.5x18	40"	16' 11"	43.75-70.75

*A tolerance of ±5" may be applied to this X dimension

Table 4 – Dimensions for Coil / Fan Sections

Box Size	X Dimension"	Rigging Tolerance ±	Coil Inlet/Outlet Distance Range
3Mx12	47"	11' 8"	All
3Mx18	51"	16' 11"	25.75-34.75
3Mx18	45"	16' 11"	43.75-70.75
12x12	57"	11' 8"	25.75-34.75
12x12	51"	11' 8"	43.75-70.75
12x18	55"	16' 11"	34.75-52.75
12x18	50"	16' 11"	52.75-70.75
12x24-D	Rig From Center	10' 8"	44.75-53.75
14x26-D	Rig From Center	11' 7"	44.75-53.76

*A tolerance of ±5" may be applied to this X dimension




Figure 7 – S Model Coil / Fan Section
– 9', 12' and 18' Long




Figure 8 – S Model Coil / Fan Section
– 18' Long




Figure 9 – D Model Coil / Fan Section
– 24' and 26' Long




Figure 10 – Mating Upper Coil / Fan Section to Basin Section

NOTE: A rigging box equipped with sealer tape and necessary fasteners is normally secured inside the pan basin for shipping. Remove the rigging box from the basin prior to assembly of sections.

Assembly of the Coil / Fan Section to the Basin Section

Before assembling the coil / fan section to the basin section, follow instructions on “Applying Sealer Tape” on page 4 and remove any loose parts shipped in the pan.

Wipe the flanges on the bottom of the coil / fan section. Check to see that the water distribution connection on the coil / fan section is in the correct position relative to the basin section (see certified print). Units are also provided with match markings on each section, as shown in Appendix A.

Lower the coil / fan section to within several inches of the basin section making sure the two sections do not touch and the sealer tape is not disturbed. Place drift pins (see **Figure 10**) in at least three of the corner mounting holes and gradually lower the coil section into place using the drift pins to guide the section down accurately onto the mating flange. On long sections, 18’ and longer, drift pins should be used midway along the sides as well.

Place fasteners in all four corner bolt holes. Then continue to install the rest of the fasteners working from the corners toward the center, using drift pins to align the holes. A fastener must be installed in every hole on the side and end flanges.

For units with two coil sections, mount the first as described, and then follow the same procedure for the second section.

Mounting Fan Screens

On 10' (3m) wide units and larger, a conical fan screen support is used in order to prevent the fan screen from sinking down into the fan cylinder. In some cases, shipping height restrictions may require the fan screen support(s) and fan screen(s) to ship loose for installation in the field. Please follow the below instructions to install these components on the fan cylinder(s).

1. Set the fan screen support across the top of the fan cylinder as shown in **Figure 11**.
2. Place both halves of the fan screen on top of the fan screen support. Each half will be tagged to match markings on the cylinder.
Align the eyelets of the fan screen with the holes on the cylinder perimeter.
3. Join the two screen halves with "U" bolts, as shown in **Figure 12**.
4. At each hole, attach the fan screen to the fan cylinder as shown in **Figure 11**.
At the four points where the fan screen support meets the cylinder, bolt the support to the cylinder together with the fan screen.




Figure 11 – Fan Screen Support & Fan Screen Installation




Figure 12 –U-Bolt Assembly Spacing & Arrangement

Note: European market sometimes utilizes alternative CE compliant fan screen with 30mm x 30mm mesh. Screen has 120mm clearance from trailing edge of fan blades.



Final Assembly & Startup Details

Shipping Materials

Remove any wood chocks, spare parts, or miscellaneous items that have been placed inside the unit for shipping purposes. Clean all debris from the basin.

Pump Discharge Line

Connect the riser pipe from the pump discharge on the basin section to the riser pipe on the coil / fan section using the flexible connection and hose clamps provided.

Makeup Water Line

Connect (plumb) the makeup water source to the makeup water connection on the unit. The makeup water supply pressure to the unit should be maintained between 20 and 50 psig. Water supply pressure in excess of 50 psig may damage the mechanical float valve.

Bleed or Blowdown

EVAPCO recommends an automated conductivity controller to maximize the water efficiency of your system. Based on recommendations from the selected water treatment company, the conductivity controller should open and close a motorized ball or solenoid valve to maintain the conductivity of the recirculating water. If the manual valve provided in the bleed-off line on a unit with factory supplied pump(s) is used to control the rate of bleed, it should be set to maintain the conductivity of the recirculating water during periods of peak load at the maximum level recommended by the selected water treatment company. If no direction is provided, the valve should be fully open. On units shipped without a pump (remote sump applications), the bleed-off arrangement and valve must be provided by the customer.

Float Valve Adjustment

The float valve is preset at the factory however adjustment should be checked after rigging. The float valve should be adjusted so that the center of the float is 1" below the center of the overflow connection when the valve is in the fully closed position. Raise or lower the float by using the wing nuts on the vertical threaded rod. Do not adjust the horizontal rod.

During normal operation, the water level will drop 3" to 4" below the overflow.

Strainer

Check the strainer in the basin to ensure that it is in its proper location over the pump suction.

Screens

Protective screens are provided across the top of the fan cylinders on all models. Inspect the screens to ensure there are no gaps that may present a safety hazard. Check all screen fasteners to ensure they are tight and secure.

Fan Rotation

Bump start and check the fans for proper rotation. Directional arrows are placed on the inside of the axial fan cylinders.

Pump Rotation

After filling the basin to the overflow with fresh water, bump start and check the pump for proper rotation. Directional arrows are found on the pump impeller housing. **Do not start pumps prior to filling the basin with water. Dry pump operation will damage the pump seals.**

Maintenance

Once installation is complete and the unit is turned on, it is important that it be properly maintained. Maintenance is not difficult or time consuming but must be done regularly to assure maximum trouble free performance of the unit. Refer to the "Operation and Maintenance Instructions" bulletin enclosed with the unit for proper maintenance procedures.

Also, proper freeze protection must be provided if the unit is located in a cold climate. Refer to the "Operation and Maintenance Instructions" bulletin supplied as well as factory product bulletins for further information. (Continued on next page)



Water Treatment and Passivation

Proper water treatment is an essential part of the maintenance required for evaporative cooling equipment. A well designed and consistently implemented water treatment program will help to ensure efficient system operation while maximizing the equipment's service life. A qualified water treatment company should design a site-specific water treatment protocol based on the equipment (including all metallurgies in the cooling system), location, makeup water quality, and usage.


"White rust" is a premature failure of the protective zinc layer on hot dip or mill galvanized steel which can occur as a result of improper water treatment control during the startup of new equipment. The initial commissioning and passivation period is critical for maximizing the service life of galvanized equipment. EVAPCO recommends that site-specific water treatment protocols include a passivation procedure which details water chemistry, any necessary chemical addition, and visual inspections during the first six (6) to twelve (12) weeks of operation. During this passivation period, recirculating water pH should be maintained above 7.0 and below 8.0 at all times. Since elevated temperatures have a harmful effect on the passivation process, the new galvanized equipment should be run without load for as much of the passivation period as is practical.

For more information on water treatment and water chemistry guidelines, refer to the "Operation and Maintenance Instructions" bulletin supplied.



Appendix A


Standard match marking location is at the rigging seam on the end and side. Standard match marking designation is shown below.




Example:

Serial Number: 23p123456 Number of Cells: 1

Match Marks: Cell #1: 56-1



FACE B



FACE A



EVAPCO, Inc. • P.O. Box 1300 • Westminster, MD 21158 USA
PHONE: 410.756.2600 • FAX: 410.756.6450 • E-MAIL: marketing@evapco.com

©2026 EVAPCO, Inc.



Printed on recycled paper
using soy-based ink