


SLOPED LADDER ARR.

DWG. # LDW22418MA-ST


NOTES:

1. LADDER AND BRACKETS SHIP LOOSE. FIELD INSTALLATION BY OTHERS IS REQUIRED.
2. REFER TO RIGGING PACK FOR LADDER AND PLATFORM MOUNTING INSTRUCTIONS.
3. RIG LADDER BEFORE INSTALLING PIPEWORK TO UNIT.

LADDER W/BRACKET ASSEMBLY WILL SHIP LOOSE FOR FIELD MOUNTING BY OTHERS.



SIDE VIEW



END VIEW

MODEL NUMBER COOLER	MODEL NUMBER CONDENSER	'X'
ATW 434-3L,3M	ATC 1191B	2378
ATW 434-4L,4M,4N	ATC 1283B,1364B,1425B	2426
ATW 434-5M,5N	ATC 1495B,1561B,1654B	2556
ATW 434-6N,6O	ATC 1708B,1783B	2575

CUSTOMER INSTALLATION NOTES:

- a. REMOVE LADDER BRACKET MOUNTING BOLTS (1) FROM LADDER MOUNTING CHANNELS (2) ON PAN AND CASING SECTIONS.
- b. LOOSEN, BUT DO NOT REMOVE, LADDER BRACKET AND ASSY. BOLTS (3).
- c. TO ASSEMBLE, SLIDE LADDER BRACKET ASSY. (4) OVER LADDER MOUNTING CHANNELS (2) LOCATED ON PAN AND CASING (DO NOT REMOVE LADDER BRACKET ASSY. (4) FROM LADDER.)
- d. ALIGN HOLES AND REINSTALL LADDER BRACKET MOUNTING BOLTS (1) THROUGH LADDER BRACKET ASSY. (4) AND LADDER MOUNTING CHANNELS (2).
- e. TIGHTEN ALL BOLTS.
- f. TIGHTEN ADJUSTING SCREW (5) IN THE ADJUSTABLE MOUNTING BRACKETS WHEN APPLICABLE.

